

12V DC

Audio out

Phones

MIDI in

MIDI out



# SOULSBY

# STRINGS

Detune Amount

Pitch LFO







Pitch Envelope

Phaser Sine Freq

Phaser Amount

Phaser Sine/WT Mix

Mono



**Amplitude Envelope**

A D S R

Gate

Invert

Arpeggiator

Run


Tie

Invert

Phaser WT

0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15

Volume



Bass Boost

