


CONTROLS

A	Fc	Filter Cutoff	B	Q	Filter Resonance
A	F Env	Filter Envelope	B	P Env	Pitch Envelope
A	F LFO	Filter LFO	B	P LFO	Pitch LFO
A	A LFO	Amplitude LFO	B	PWM	Pulse Width Modulation
A	Dist	Distortion	B	Phase	Phaser
A	Volume	Output volume	B	Pitch	Play button pitch

MIDI

You will need to flash the Arduino's USB processor if not MIDI-hacked. Find out how to do this at: www.soulsbysynths.com/tutorials



MIDI mode
(no jumper)

Arduino mode
(with jumper)

Go to www.soulsbysynths.com for more detailed instructions, tables of settings and the latest software.

©2015 Soulsby Synthesizers. All rights reserved.



SOULSBY

miniATMEGATRON


ASSEMBLY AND OPERATION INSTRUCTIONS

FUNCTION

	Waveform select		LFO shape
	Filter type		LFO speed
	Filter/pitch envelope		Wavecrusher/Portamento
	Amplitude envelope		Pattern select

VALUE

Value is between 0-15. Also shows pattern beat. E.g.:



Hold Func + & press Value -/+ = Pattern Tempo

Hold Func - = Save Patch